









FROM POWER SOURCE SYSTEM (SEE PAGE 188)



FROM POWER SOURCE SYSTEM (SEE PAGE 188)



FROM POWER SOURCE SYSTEM (SEE PAGE 188)







LS430 (EWD435F)




LS430 (EWD435F)




Адаптеры для свапа GOSWAP.KZ



LS430 (EWD435F)




LS430 (EWD435F)



LS430 (EWD435F)



Адаптеры для свапа GOSWAP.KZ




LS430 (EWD435F)



Celsior / LS430 UCF30 5AT
STARTING AND IGNITION (RHD)

FROM POWER SOURCE SYSTEM (SEE PAGE 188)






- * 1 : EUROPE
- * 2 : AUSTRALIA
- * 3 : CHECK ENGINE (+1)
- * 4 : W/ LEXUS NAVIGATION SYSTEM
- * 5 : W/O LEXUS NAVIGATION SYSTEM
- * 6 : W/O ELECTRONIC MODULATED AIR SUSPENSION



- * 4 : W/ LEXUS NAVIGATION SYSTEM
- * 5 : W/O LEXUS NAVIGATION SYSTEM
- * 7 : W/ LEXUS PARK ASSIST (CLEARANCE SONAR)



Celsior / LS430 UCF30 5AT

SHIFT LOCK (RHD)

